




Tandberg System – user guide

Using the remote control



Making a call

You can dial ISDN numbers, or IP numbers.



Ending a call



Moving the camera



When the menu is hidden, the arrow keys will work on the camera.

If the menu is displayed, **press the Cancel button on the remote control to hide it.**

Displaying Sources

1

Press the **Menu** button on the remote



2

Press to **start presentation menu**



Main Camera

PC

Doc Cam

VCR

Select the source to be sent


3

Alternate method for accessing the Presentation Menu



Press and hold the **Presentation** button on the remote until the presentation menu pops up.

1




Select the source to be sent

2

Using camera presets

Presets are only available while in a call to show:



Changing Screen Layout

